



WE OUTFIT THE WEST WITH SLATWALL PANELING

Spacewall West, Inc.

www.spacewallwest.com

CALIFORNIA

Tel: 714.961.1300

800.643.4952

Fax: 714.961.0976

350 East Crowther Avenue

Placentia, California 92870

WASHINGTON

Tel: 253.852.0203

800.433.7099

Fax: 253.852.0204

25315 74th Avenue S. Ste. 102

Kent, Washington 98032

CARE AND MAINTENANCE INSTRUCTIONS

Spacewall slatwall paneling with high pressure laminate or melamine is best cleaned by wiping it with a soft, damp cloth and a mild detergent; followed by wiping it with a cloth of damp warm water, and finally, wiping the panel with a dry cloth to remove any cleaner residue. It is important not to get the panel wet because the substrate is very porous and is not designed as a water-resistant material. Suggested cleaners are Pine Sol or Mr. Clean. Abrasive pads and scouring powder should not be used. Harsh chemical cleaners such as toilet bowl cleaners, hydrogen peroxide, and drain cleaners should be avoided.

Acrylic mirror should be cleaned using a commercial acrylic polish. You can also use Pledge to clean the mirror and help with static resistance. Do not use ammonia-based cleaners, such as Windex, to clean acrylic mirror. The chemicals will permanently damage the mirror and the surface will dull and cloud.

Wipe the slatwall slats with a damp cloth running the cloth from one end of the slat to the other.



Association for
Retail Environments